

Updating the JRVCS1

- 1) Click on each link below **Software Updates** under RESOURCES.
Each file will download. Make sure you do not change the file names, place them within folders, or unzip the zipped file. Move the downloads to your flash drive - you'll need no less than 1GB of storage.
 - If you're not sure of which system you have and want to make absolutely sure you're downloading the proper updates, go to <https://in-command.net/control-systems/> and select the system that matches the one in your RV.
- 2) Insert the flash drive into the bottom of your Display Commander.
- 3) Press **Menu** at the bottom of the home screen.
- 4) Press Setup in the bottom right, it will ask you for the Engineer's Passcode - it is **5391**.
- 5) You should see DC/BCM Version. To the right of each of these you'll see an Update button. You'll want to update the DC and the BCM Versions one at a time. They'll have you reboot the display to finalize the updates.

If you see an error "Can't find firmware on USB disk!!!", the update files are not properly on the flash drive or the drive is corrupt.

