

# Resetting NCSP3 and NCSP35

- 1) Press and hold the Power Button until the display gives you an option on screen to *Power Off* - press this.
- 2) Once the display is completely black, exit the vehicle and find the BCM.
- 3) Remove the cover of the BCM to expose the green board.
- 4) Press and hold the Reset button for 2 Seconds and let go.
- 5) Press and hold the Power button until the display shows light.

